

Oracle 1z0-546

StorageTek Tape Libraries Essentials

Version: 4.0

QUESTION NO: 1

Which of the items are reports available from SLC regarding partitioning on an SL500?

- A. Cartridge Cell and Media Summary
- B. Host Connections Summary
- C. Orphaned Cartridge Report
- D. Partition Summary
- E. Partition Details
- F. All of the above

Answer: F

Explanation: Partitions—Reports include:

Partitions—Reports—Cartridge Cell and Media Summary

Partitions—Reports—Host Connections Summary

Partitions—Reports—Orphaned Cartridge Report

Partitions—Reports—Partition Details

Partitions—Reports—Partition Summary

Reference: StorageTek SL500 Modular Library System, Partition Report Screens

QUESTION NO: 2

What ACSLS command would change a cap priority?

- A. set cap priority 5 0, 0, 1
- B. define cap priority 5 0,0,1
- C. change cap priority 5 0, 0, 1
- D. lock cap priority 5 0, 0, 1

Answer: A

Explanation: A: The set cap priority command sets a CAP's automatic selection priority.

Format

set cap priority cap_priority cap_id

Reference: StorageTek ACSLS, Automated Cartridge System Library Software , set cap priority

QUESTION NO: 3

Using ACSLS, how would you delete a tape pool?

- A. Set scr off and delete the pool
- B. Remove all data tapes and delete the pool
- C. Delete pool 0 and all empty pools will delete automatically
- D. Remove all volumes from the pool and then delete it

Answer: A

Explanation: Use the delete pool command to delete empty scratch pools. If a pool contains scratch cartridges, you must reassign these cartridges to another pool before deleting the first pool. If a scratch cartridge is mounted, it becomes a data cartridge but remains in its scratch pool. Use the set scratch off command to reassign the data cartridge to the common pool.

Reference: StorageTek ACSLS, Automated Cartridge System Library Software , delete pool

QUESTION NO: 4

Which connectivity option is available only in an SL8500 library complex?

- A. single TCP/IP connectivity
- B. dual TCP/IP connectivity
- C. multi TCP/IP connectivity

Answer: B

Explanation: The SL8500 library uses TCP/IP protocol over an Ethernet physical interface to manage and communicate with the library. This interface enables both enterprise-level (HSC) and open system platforms (ACSL) to connect to and communicate with the SL8500.

There are two separate Ethernet connections on the HBC card for host to library communications—Ports 2A and 2B.

* Port 2A provides the Dual TCP/IP host connection—this is an optional feature for SL8500 libraries..

* Port 2B provides the primary connection for host communications—this is the standard connection for SL8500 libraries.

Reference: StorageTek StreamLine SL8500, modular library system, Host Interfaces

QUESTION NO: 5

Where are the messages written when a pool gets below the low water mark?

- A. acsss_event.log
- B. pool_error.log
- C. hardware_event.log
- D. Doesn't write an error message

Answer: A

Explanation: low_water_mark

is the low volume warning threshold. If the scratch cartridge count falls below this threshold, ACSLS logs a warning message in the event log. Valid values are 0 to 231-1. The default is 0.

Note: The ACSLS event log is the first stop for useful information in the event of problems with your library operation. This log contains information about library events, status changes, and errors. All sub-components within ACSLS will report events to the acsss_event.log by sending messages to a process called the event logger. The standard event log, which is automatically created when ACSLS is installed, is contained in the file `$ACS_HOME/log/acsss_event.log` and where `$ACS_HOME` is usually `/export/home/ACSSS/`.

Reference: StorageTek ACSLS, Automated Cartridge System Library Software , define pool

QUESTION NO: 6

On the SL8500, which is the best option when combining workloads that span more than one rail?

- A. using the middle two rails for active enters and ejects
- B. using rails that are adjacent to each other within the same SL8500
- C. using the top rail for extra archival space and any other rail for active data
- D. using the top rail for active enters and ejects and any other rail for archival space

Answer: C

Explanation: If you are not able to assign workloads to a single rail, consider:

- * Using rails that are adjacent to each other. This provides a shorter distance for the pass-thru operation.
- * Combining rails vertically rather than horizontally

Reference: StorageTek SL8500 Modular Library System, Best Practises, Dedicating Rails

QUESTION NO: 7

The System Detail SLC screen displays health indicators for which four devices in an SL3000?

- A. Rotational and AFM CAPs
- B. Drives
- C. Media
- D. Power supplies
- E. Robot(s)


Answer: A,B,D,E

Explanation: The SL Console screen displays health indicators for each of the following devices:

- * Library
- * Rotational and AEM CAPs (A)
- * Drives (B)
- * Power supplies (D)
- * Robot(s) (E)
- * AEM safety doors

Please reference the figure below.

FIGURE 6-1 SL Console Health Status Indicators



Reference: StorageTek SL3000 Modular Library System, User's Guide , Library and Device Status

QUESTION NO: 8

Which four statements are true for an SL8500?

- A. Partitioned LSMs will not recognize other LSMs, within the library unless they are in the same partition.
- B. The elevator operation is under the control of the library controller when CAP operations are issued.
- C. CAPS can either be shared or dedicated resources for partitions.
- D. All drives, storage slots, and cartridges within a partition are solely owned by that host or host group.
- E. While duplicate VOLSERS are supported by the library, ACSLS does not support duplicate VOLSERS unless they are in different partitions and the duplicate VOLSERS are on different ACLS servers.

Answer: B,C,D,E

Explanation:

B: Elevator operation is under the control of the library controller when CAP operations are issued. The library controller uses the elevators and HandBots to access the entire capacity of the CAPs for enters and ejects without regard for the partitions.

Note: Elevators provide vertical pass-thru operations between rails within the same library. Both elevators are located in the front of the library between the front access doors and the Service Safety Door. Each of the four rails share the two elevators.

C: Partitions share the ownership of the CAPs. That is, if one host/partition has CAP A reserved, a different host/partition can have CAP B reserved, or one host/partition can have both CAPs reserved.

D: Elevators, robots, and CAPs are shared resources and—each partition can fully use shared resources for cartridge movement, enter, and eject operations. All drives, storage slots and cartridges within a partition are solely owned by that host or host group.

E: Duplicate VOLSERS are supported by the library; however, ACSLS and HSC do not, unless:

*The duplicate VOLSERS are in different partitions.

* With HSC managed partitions, the duplicate VOLSERS are in different control data sets.

* With ACSLS managed partitions, the duplicate VOLSERS are managed by different ACSLS

servers.

Note. volume serial numbers (VOLSERs)

Reference; StorageTek SL8500 Modular Library System, Best Practises,Guidelines

QUESTION NO: 9

Which SL500 report displays the current map of physical drive slot relationship to its physical address (iib, module, row) and drive serial number?

- A. Library Utilization
- B. Drive Utilization
- C. Drive Mapping
- D. Drive Distribution

Answer: C

Explanation: The Current Drive Mapping report lists the library internal address and drive serial number currently assigned to each physical drive slot in the library.

Reference: StorageTek SL500 Modular Library System, Users Guide, Display Current Drive Mappings

QUESTION NO: 10

Partitioning allows the SL3000 library to be divided for use by multiple_____.

- A. Power Supplies
- B. Storage Cells
- C. Hosts
- D. Drives

Answer: C

Explanation: Library resources (cells, drives, and CAPs) are allocated to a partition for exclusive use by that partition. Storage cells, CAPs, and tape drives allocated to a partition can be used only by the hosts assigned to that partition.

Storage cells, CAPs, and drives not allocated to, reserved for or associated with any partition

cannot be accessed by any hosts.

Reference: StorageTek SL3000 Modular Library System, User's Guide, Partitioning Concepts and Features

QUESTION NO: 11

Which three rules apply when the SL3000 library controller automatically adds cells to active storage regions?

- A. Cell activation starts in the left upper rear of the active storage region and moves to the right lower front
- B. Cell activation starts with the cells closest to the drives and moves out equally from right to left and top to bottom
- C. All cells within a column are activated from top to bottom before moving to the next column
- D. Columns within a panel are activated from left to right

Answer: A,C,D

Explanation: Cell Activation Rules

The library controller uses the following rules when adding cells to active storage regions:

- * Cell activation starts in the left upper rear of the active storage region and moves to the right lower front.
- * All cells within a column are activated from top to bottom before moving to the next column.
- * Columns within a panel are activated from left to right.

Reference: StorageTek SL3000 Modular Library System, User's Guide, Cell Activation Rules

QUESTION NO: 12

Which three growth features can be installed nondisruptively to the SL8500?

- A. Capacity on Demand
- B. Pass thru Ports
- C. Cartridge Expansion Frames
- D. Another Library

Answer: A,B,C

Explanation: A: The SL3000 library includes RealTimeGrowth and Capacity on Demand features.